

## Outdoor Jacket With Pockets - Sewing Pattern #2137

Recommendations on fabric: raincoat fabrics, natural/mixed jeans fabrics.

You will also need: 12 push buttons; cord; 2 eyelets.

Seam allowances: all seams 1 cm; seam allowance along lower edge - 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Front yoke — cut 2
6. Stand collar - cut 2
7. Back yoke — cut 1
8. Upper sleeve - cut 2

9. Lower sleeve – cut 2
10. Lower part plackets – cut 2
11. Upper part plackets – cut 2
12. Cuff — cut 2
13. Casing - cut 1
14. Flap – cut 4
15. Pocket – cut 2

## INSTRUCTIONS:

1. Sew side backs to center back. Serge seams and press towards center. Sew a decorative stitchline at 0.5 cm from seam. Sew center back seam. Serge seam and press towards left. Sew back yoke to yoke. Serge, press towards top and topstitch at 0.5 cm from seam.
2. Sew side front to center front. Serge seams and press towards center. Sew a decorative stitchline at 0.5 cm from seam. Sew yoke to front. Serge, press onto yoke and sew a decorative stitch at 0.5 cm from seam.
3. Pin flaps together, right sides together and sew along side edges and along lower edge. Trim seam allowances, turn the flap right side out and press. Serge the raw edge. Sew a decorative stitch at 0.5 cm from the edge. Serge pocket around all edges. Turn the upper edge under and topstitch. Press the side seam allowance and the lower seam allowance of the pocket onto the wrong side. Pin pocket onto front and topstitch. Sew flap to front above the pocket, fold towards bottom and topstitch. Sew a decorative stitch around all edges at 0.5 cm from the edge.
4. Sew side and shoulder seams on Shell. Serge seams and press towards back.
5. Turn under the seam allowances along the lower edges of the casing and press. Seam allowance along short edges of casing turn inside and topstitch. Topstitch casing onto the main piece from the wrong side according to markings.
6. Serge separately the edges of the back sleeve seam. Sew elbow seam on the sleeve up to notch, marking the slit. Sew front sleeve seam, serge and press towards upper piece. Fold cuff in half lengthwise, right sides together and sew corners and the protruding section. Trim seam allowances, turn right side out and press. Sew outer side of cuff to sleeve. Fold under the seam allowance of the inner side inside and topstitch into seam of. Sew a decorative stitch around all edges cuffs at 0.5 cm from the edge. Sew sleeves into armholes.
7. Pin together stand collars right sides together and sew upper edge. Stand collar turn right side out and press. Sew outer stand collar into neckline of Shell. Fold under the seam allowance of the inner stand collar and stitch in the ditch.
8. Sew the placket seam. Press seam allowance towards top and press. Sew a decorative stitch at 0.5 cm from seam. Fold placket in half lengthwise right sides together and sew upper and lower edges, start and stop stitching exactly at the marked line of the center front edge. Trim away corners, turn the piece right side out

and press. Sew the outer edge of the placket to center front edge, press seam allowance towards the placket. Fold under the inner edge of the placket and topstitch into seam of. Sew a decorative stitch at 0.5 cm from seam.

9. Fold under the lower sleeve at 1 cm and press, then at 2 cm and topstitch.
10. Sew a decorative stitchline around all edges stand collars, around all edges plackets.
11. Install push buttons on placket, on cuffs and on flaps.
12. Thread cord into casing, attach cord ends.

## **TECHNICAL DRAWING:**

