

Dress-Jacket With Slanted Closure - Sewing Pattern #2197

Recommendations on fabric: natural/mixed suiting fabric.

You will also need: fusible interfacing; lining; 3 buttons; 1 inner button; shoulder pads, sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Center right front - cut 1
3. Center left front - cut 1
4. Side front - cut 2
5. Sleeve - cut 2
6. Back neck facing - cut 1
7. Center front facing left - cut 1

8. Center front facing right – cut 1

Fusible interfacing: back neck facing, center front facing right, center front facing left.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back. Press bulk towards center. Sew center back seam. Serge the seam allowances and press towards left.
3. Sew side fronts to center front. Serge seams and press towards center.
4. Sew shoulder and side seams of dress. Serge seams and press towards back.
5. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes matching notches. Sew shoulder pads, sew sleeve heads.
6. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing. Serge the outer edge.
7. Place center front facing onto front right sides together, pin together and sew along center front, along lower edge, and along neckline. Clip seam allowances, trim away corner. Center front facing and fold facing onto wrong side and press.
8. Serge seam allowances along hem of dress and hem of sleeves, fold inside onto wrong side and finish with hidden stitches.
9. Make buttonholes on right front, and sew on buttons onto left front. Make an inner buttonhole on left front and sew on inner button.

TECHNICAL DRAWING:

