

Coat With Patch Pockets - Sewing Pattern #2199

Recommendations on fabric: natural/mixed fabrics suitable for coats.

You will also need: fusible interfacing; lining; shoulder pads; 1 inner button; 4 ready closures.

Seam allowances: all seams 1 cm. Seam allowance for hem – 3 cm. Outer edge of hood – 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Hood - cut 2
4. Center front facing – cut 2
5. Back neck facing – cut 1
6. Upper sleeve – cut 2

7. Lower sleeve – cut 2
8. Cuff – cut 4
9. Front yoke – cut 2
10. Back yoke – cut 1
11. Pocket – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1
3. Cuff – cut 2
4. Front yoke – cut 2

Lining:

1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Hood – cut 2
6. Back yoke – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the outer seam allowance of the hood.
2. Sew and press apart center back seam. Pin back yoke to yoke lining, sew along the side edges and the lower edge. Trim away corners, yoke turn right side out and press. Pin yoke onto back and baste together along the shoulder edges and neckline edge. Slip stitch yoke to back along the center seam from the wrong side.
3. Sew darts on front. Press bulk towards top. Sew yoke to front. Press seam towards yoke. Fold away yoke towards top, press along the marked line of the fold and sew a decorative stitch at 2 cm from the edge.
4. Serge pocket around all edges. Fold under the upper seam allowance of pocket and topstitch. Fold inside side and lower seam allowances inside and press. Topstitch pocket onto front according to markings.
5. Sew and press apart the shoulder and side edges of the coat.
6. Sew hood seam. Press the seam apart. Sew the seam on the hood lining. Press towards left. Make and baste pleats on hood and on lining. Direct the bulk towards the shoulder edge. Pin hood to lining right sides together and sew the outer edge. Press towards the lining. Sew a fixing stitch along the outer edge of the hood at 1 cm from the edge. Sew the hood into the coat's neckline.
7. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing.

8. Make an inner button hole on center front facing. Place center front facing onto front right sides together, pin together and sew along the center front edge, along neckline and lower corner.
9. Sew elbow seam on sleeve. Press the seam apart. Sew front seam on sleeve. Press the seam apart. Sew cuff into a ring, from upper edge to the mark for slit. Clip into seam allowance near the notch and press apart. Pin together cuffs pairwise right sides together and sew slit edge and lower edge. Trim away corners, turn right side out and press. Sew upper cuff to sleeve, press the seam apart. Sew sleeves into armholes. Press seam.
10. Sew the pieces from lining, leaving an opening in left elbow seam. Sew lining to back neckline facing, to center front facing and to hem of coat. Turn coat right side out through the opening. Sew lining to hem of sleeve, press seam allowance towards top. Baste seam allowances on cuff together. Sew the opening closed.
11. Sew on inner button. Topstitch the left part of the ready closure onto the left front. Topstitch the right part of the button loop onto the right front, correspondingly.

TECHNICAL DRAWING:

