

Dress With Tie On The Waist - Sewing Pattern #2240

Recommendations on fabric: natural/mixed knit fabric of small stretchiness in contrasting or similar color.

You will also need: knit fusible interfacing.

Seam allowances: all seams 1 cm; seam allowance for hem of dress – 2.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Lower back - cut 2
2. Lower front - cut 1 on fold
3. Front side - cut 2
4. Pocket bag - cut 2
5. Sleeve - cut 2
6. Back neck facing - cut 2
7. Front neck facing - cut 4

8. Casing - cut 1

Main fabric 1:

1. Upper back - cut 2
2. Upper front - cut 1 on fold
3. Cuff - cut 2

Fusible interfacing:

1. Back neck facing - cut 1
2. Front neck facing - cut 2
3. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on Upper Front, press bulk towards top.
3. Sew side and shoulder edges of upper backs and upper fronts, press towards the back and serge.
4. Sew pairwise back neck facing and front neck facing, press the seam apart. Pin together facings right sides together and sew the outer edge. Clip into curves, trim away corners, turn the piece right side out, straighten, press. Sew neckline facing into neckline, press towards the main piece and topstitch at 0.7 cm from seam.
5. Apply fusible interfacing to pocket opening area on lower front. Pin pocket bag onto lower front right sides together and sew pocket opening. Fold pocket bag onto wrong side, press. Pin lower front at front side and sew edges of pocket bags, serge. Baste pieces together by боковому and верхнему срезам.
6. Sew side seams on lower fronts and lower backs, press towards the back and serge.
7. Serge the shorter edges of casing, press onto wrong side and topstitch. Fold under the upper edge of casing and press. Sew upper part to lower part, inserting the lower edge of the casing into the seam, press towards top and serge. Topstitch casing onto garment long the upper fold.
8. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes matching notches and adjusting ease, serge and press.
9. Fold cuff in half lengthwise right sides together and sew short sides. Turn the piece right side out, straighten, press. Sew cuff to lower edge of sleeve, placing shorter edges near notch. Press towards sleeve, serge and topstitch at 0.7 cm from seam.
10. Serge bottom edge of garment, press onto wrong side and topstitch.

11. Cut a tie from main fabric 1, its width should equal 4 cm and its length should equal waist circumference multiplied by 2. Fold tie in half lengthwise wrong sides together and press. Straighten the piece, fold the edges to the center line, press again. Topstitch at 0.1 cm from the edge. Thread the tie into the casing.

TECHNICAL DRAWING:

