

Jacket Without Closure - Sewing Pattern #2248

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 2 decorative of the zipper.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Stand collar — cut 2
6. Center front facing — cut 2
7. Back neck facing - cut 1

8. Upper sleeve – cut 2
9. Lower sleeve – cut 2
10. Cuff — cut 2

Lining is cut using the pattern blocks for self fabric, except for the width of back neckline facing.

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Front lining – cut 2
4. Upper sleeve – cut 2
5. Lower sleeve – cut 2

Fusible interfacing:

1. Stand collar — cut 1
2. Center front facing — cut 2
3. Back neck facing – cut 1
4. Cuff — cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew side backs to center back, press towards center. Sew the center back seam, press the seam apart.
3. Sew side fronts to front, press towards center. Topstitch zipper onto the princess seam.
4. Sew shoulder and side seams, press the seam apart.
5. Pin together parts of stand collar, right sides together and sew ends and outer edge. Clip into curves, trim away corners. Turn stand collar right side out, straighten, press. Sew the stand collar into neckline.
6. Sew side seams of center front facings and back neckline facings, press the seam apart. Pin center front facings onto garment, right sides together, and sew center front edge, neckline (stand collar is placed between facing and shell) and lower corner of center front. Clip into curves, trim away corners, turn pieces right side out. Sew a decorative stitch along center front edge and the front part of the neckline up to stand collar at 0.5 – 0.7 cm.
7. Sew elbow seam on sleeve, press the seam apart. Press the hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise and press right side out. Sew outer

side of cuff to the lower edge of sleeve, press towards cuff.

9. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, leaving an opening in left elbow seam of sleeve. Sew lining to facing and to central front facings. Turn garment right side out, straighten seams.

10. Mark and press lower edge of garment. Sew lining to the lower edge of garment and to the inner side of cuff. Sew the opening closed. Fold cuff onto sleeve.

TECHNICAL DRAWING:

