

Jacket With Decorative Darts - Sewing Pattern #2254

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 1 button.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Center front facing - cut 2
6. Back neck facing - cut 1
7. Upper sleeve - cut 2

8. Lower sleeve – cut 2

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Attention: center back and center front from lining are cut using pattern blocks for self fabric except for the width of back neckline facing and center front facing correspondingly.

Fusible interfacing:

1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Cut a tape from fusible interfacing and apply along edge of back neckline. Apply fusible interfacing to the lower edge of garment and to lower edge of sleeve.
2. Sew dart on center back. Press bulk towards center, sew a decorative stitch at 0.1 cm from seam. Serge separately, sew and press apart princess seams on the back (sew side backs to center backs). Sew and press apart center back seam.
3. Sew dart from shoulder edge on center front. Press bulk towards center, sew a decorative stitch at 0.1 cm from seam. Fold center front wrong sides together and stitch horizontal darts, press bulk towards bottom. Sew princess seam on front and press the seam apart.
4. Sew and press apart shoulder and side seams.
5. Sew side seams of back neckline facing and central front facings, press seam apart. Pin center front facings onto garment and sew center edges and neckline with one continuous seam. Trim seam allowances in corners, clip into curves, turn garment right side out, press. Topstitch seam allowance of the central front facing onto the central front facing. Place stitch line at 0,2 cm from seam. Press lower edge of garment.
6. Sew the elbow seam of the sleeve and press it apart, adjusting ease on upper part of sleeve and matching notches. Press the hem of sleeve. Fold away seam allowance on hem, sew and press apart front sleeve seam.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.

8. Sew seams on lining and sew in sleeves, leaving an opening for turning in left elbow seam. Sew lining to inner edges of center front facings and of facing.
9. Sew lining to lower edge of garment and lower edge of sleeve. Turn jacket right side out. Sew the opening closed.
10. Make buttonhole on right front, on left front sew on a button.

TECHNICAL DRAWING:

