

Dress - Sewing Pattern #2290

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; 9 buttons; decorative cord.

Seam allowances: all seam allowances – 1.0 cm. Seam allowance for hem of garment – 2 cm.

Note on seam allowances:

If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

- 1. Upper back cut 2
- 2. Lower back cut 2
- 3. Upper front cut 2
- 4. Lower front cut 2
- 5. Sleeve cut 2
- 6. Cuff cut 2
- 7. Sleeve decorative tab cut 2



8. Collar - cut 2
 9. Stand collar - cut 2
 10. Front side - cut 2
 11. Pocket bag - cut 2
 12. Back belt - cut 1
 13. Front belt - cut 1
 Fusible interfacing:

Collar - cut 1
 Stand collar - cut 1

3. Cuff – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to the one-piece center front facing on upper front.

2. Sew center seam of upper back, press towards left and serge. Sew center edges on lower backs and полочки, press towards left and serge.

3. Sew bust darts on fronts, press bulk towards top.

4. Serge the edge of the one-piece center front facing on the upper front. Press center front facing onto wrong side, baste to the main piece along the upper and the lower edges. Make buttonholes on right front. Put right front onto left front and baste together along lower edge.

5. Sew side and shoulder edges of upper backs and upper fronts, press towards the back and serge.

6. Pin together collars right sides together and sew ends and collar fall. Trim seam allowances, turn the collar right side out, straighten and press. Sew a decorative stitch around all edges. Pin together parts of stand collar, right sides together and sew, inserting collar. Start and stop stitching exactly at the marked seam of stand collar into neckline. Trim seam allowances, turn stand collar right side out and press.

7. Sew outer stand collar into neckline, press seam allowances towards stand collar. Fold under the edge of the inner stand collar and stitch-in-the-ditch into the seam.

8. Apply fusible interfacing to pocket opening area on lower front. Pin pocket bag onto lower front right sides together and sew pocket opening. Clip seam allowances. Fold pocket bag onto wrong side, press. Pin lower front at front side and sew edges of pocket bags, serge. Baste pieces together by боковому and верхнему срезам.

9. Sew side seams on lower fronts and lower backs, press towards the back and serge.

10. Sew side seams of back belt and front belt, press the seam apart. press onto wrong side upper edge. Serge



according to markings button loops. Sew upper part to lower part, inserting the lower edge of belt into the seam, press towards top and serge. Topstitch the belt onto garment along the upper fold line, making a casing.

11. Fold decorative tabs in half lengthwise right sides together and sew along longer and one shorter edge. Turn right side out, slashing seam allowances in corners, straighten and press. Serge raw shorter edge. Topstitch decorative tabs according to the markings onto the wrong side of sleeves.

12. Serge the sleeve edges separately. Sew sleeve seam from armhole to notch, press the seam apart. Sew a fastening stitch along the slit at 0.1 cm from the edge. Sew sleeves into armholes, serge and press.

13. Fold cuff in half lengthwise, right sides together and sew side seams. Turn the piece right side out, press. Sew the outer part of the cuff to the sleeve, fold inside the inner side of the cuff, and topstitch into the seam of the outer cuff cuffs.

14. Serge the lower edge of garment, press onto wrong side and topstitch.

15. Sew on buttons on left upper front. Make button holes and sew on buttons on stand collar and cuffs. Make buttonholes on decorative tabs, sew on buttons onto sleeves.

16. Thread in the decorative cord into casing.

TECHNICAL DRAWING:



