

## Blouse With Trimming - Sewing Pattern #2313

Recommendations on fabric: natural/mixed fabrics suitable for blouses in two contrasting or matching colours.

You will also need: fusible interfacing.

Seam allowances: Seam allowance for hem of garment - 2 cm, other seams - 1 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## CUTTING:

### Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Upper front - cut 2
3. Lower front - cut 1 on fold
4. Neckline facing - cut 1

Main fabric 1:

1. Cuff - cut 2

- 2. Sleeve inset – cut 2
- 3. Placket – cut 4

Fusible interfacing:

- 1. Neckline facing – cut 1
- 2. Placket – cut 2

## **INSTRUCTIONS:**

1. Sew sleeve inset to the shoulder seam of Front and Back. Serge the seam allowances and press towards inset.
2. Serge the outer edge facings. Pin facing onto neckline right side down and sew neckline. Clip into seam allowance, turn facing onto wrong side and press.
3. Pin together plackets right sides together and sew the outer edge and the upper edge. Turn right side out and press.
4. Place placket onto Front, right sides of both pieces being upwards and sew. Serge and press. Pin right placket onto left placket and topstitch along the vertical part.
5. Make and baste a box pleat on lower front. Sew upper front to lower front. Serge and press towards bottom.
6. Sew side seams processing the sleeve seam at the same time, press towards the back and serge.
7. Sew cuff into a ring. Press the seam allowances apart. Fold cuff in half lengthwise and press. Pin cuff onto wrong side of sleeve and sew. Serge the seam. Fold cuff to right side. Fix cuff near the placket seam.
8. Serge the lower edge of garment, press onto wrong side and topstitch.

## **TECHNICAL DRAWING:**

