

## Jumpsuit With Pockets - Sewing Pattern #2318

Recommendations on fabric: natural/mixed silk fabrics.

You will also need: fusible interfacing, elastic tape 0.7 cm wide, 3 buttons.

Seam allowances: seam allowance along the upper edge of the front shorts and the back shorts, as well as along the lower edge of back and of front — 2 cm. Seam allowance along the lower edge of the front halves and the back halves – 2 cm. Other seams 1 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## CUTTING:

### Note on cutting:

On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold
2. Front – cut 2
3. Front half — cut 2
4. Back half — cut 2
5. Side — cut 2
6. Pocket bag — cut 2

7. Center front facing — cut 2
8. Back neck facing — cut 1

Fusible interfacing:

1. Center front facing — cut 2
2. Back neck facing — cut 1

## INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to the pocket opening seam allowances on the front halves.
2. Pin pocket bag onto front half and sew pocket opening. Turn pocket bag onto the wrong side, topstitch seam allowances onto pocket bag at 0.1 cm and press.
3. Pin front half onto side according to markings. Sew pocket bag to side, serge. Baste pocket bag to the front half along the upper and the side edges.
4. Sew center seams of the back halves and the front halves of shorts, press the seam apart and serge. Sew side seams on shorts, press towards the back and serge. Sew inside leg seam, press towards the back and serge.
5. Sew shoulder and side seams on backs and fronts, press towards the back and serge.
6. Sew shoulder seams of central front facings and facings, press the seam apart. Serge the outer edge. Pin center front facings onto garment right sides together and sew center front edge and back neckline. Clip into curves, trim away corners. Turn the center front facings onto wrong side, straighten and press. Slipstitch to garment along the shoulder seams. Pin right front onto left front matching center front line and baste together along lower edge. Sew a gathering stitch along the lower edge of front and gather fullness.
7. Pin bodice to shorts wrong sides together. Sew at 0.7 cm from the edge. Turn pieces wrong side out, press and sew one more time at 1.3 cm from seam. Press towards bottom. Topstitch seam allowance onto shorts. Carefully slash an opening for elastic band and serge by hand. Thread in elastic band and slipstitch.
8. Seam allowance along hem press towards 1 cm, then again at 1 cm and topstitch.
9. Make buttonholes on right front, sew on buttons on the left one.

## TECHNICAL DRAWING:

