

Jacket With Decorative Peplum - Sewing Pattern #2386

Recommendations on fabric: thin soft natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 5 buttons.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve - 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Placket - cut 2
5. Peplum - cut 1
6. Back neck facing - cut 1
7. Front neck facing - cut 2

8. Belt – cut 2

Lining:

1. Back – cut 1 on fold
2. Front – cut 2
3. Sleeve – cut 2
4. Lining of hidden button panel – cut 2

Fusible interfacing:

1. Placket – cut 2
2. Back neck facing – cut 1
3. Front neck facing – cut 2
4. Lining of hidden button panel – cut 1

Attention! Cut Back and Front from lining using the corresponding pieces for main fabric except for the width of back neckline facing and front neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on front, press bulk towards top.
3. Sew right side seam, press the seam apart.
4. Serge lower edge of peplum, press onto wrong side and topstitch. Serge the upper edge of peplum, press onto wrong side along the marked line and topstitch with gathering stitch, gather fullness. Pin peplum onto right Front and Back of jacket and topstitch.
5. Fold belts in half lengthwise right sides together and sew the longer side and the shorter side. Turn belt right side out, straighten, press.
6. Sew left side seam, inserting the left side of belt, and shoulder seams, press the seam apart.
7. Sew sleeve seam, press the seam apart. Sew sleeves into armholes matching notches, press seam.
8. Sew the shoulder edges of back neckline facing and front neckline facing and press apart. Sew together pieces of lining in the same way as you have sewn pieces from main fabric, press the seam apart. Sew facing to lining, press seam allowances towards placket.
9. Pin lining to Front right sides together and sew the neckline. Clip into curves, turn garment right side out, straighten seams, press. Sew lining to lower edge of garment and lower edge of sleeve. Baste together main fabric and lining along center front edge.

10. Mark the slit for closure on the inner side of the right placket with three lines: first line is parallel to center front edge and is placed at 1.5 cm from center front edge on ready garment, the second and the third lines mark the length of closure. Pin lining with fusing interfacing applied onto right side of placket, right side down, directed away from the fold on center front edge, align edge of lining and marked line. Sew a stitch line at 0.5 cm from marked line along the closure slit up to the lines marking the length of closure. Pin second lining exactly matching the edge of second lining and stitch line of first lining and sew a stitch line at 0.5 cm. Verify that the stitch lines are parallel from the wrong side. Cut the slit for closure. Make slashed cuts at 1-1.5 cm from the end of slit. Turn the lining onto wrong side, making a frame, which equals the distance between stitch lines. Sew a fixing stitch in the ditch along the seam of the first lining. Press second lining towards inner edge of placket and sew a fixing stitch line at 0.1 cm from the seam of lining. Mark and make buttonholes (through all layers of main fabric and linings). Straighten and fix ends of closure from the wrong side with double back stitch at the corners. Sew edges of lining. Sew short fixing stitches between each pair of buttonholes.

11. Pin together plackets in half lengthwise right sides together and sew upper and lower edge. Start and stop stitching exactly at the marked line of the placket seam. Trim away corners, turn the plackets onto right side, straighten, press. Sew the outer edge of placket to garment, inserting the right side of belt, fold under the inner edge of placket and topstitch into the seam of the outer placket.

12. Sew on buttons on left placket.

TECHNICAL DRAWING:

