

Jacket With Decorative Collar - Sewing Pattern #4433

Recommendations on fabric: thin natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; thin shoulder pads; 1 button.

Seam allowances: all seams 1 cm. Seam allowance for hem of sleeve 3.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Right center front – cut 1
5. Left center front — cut 1
6. Center front facing of left front – cut 1
7. Center front facing of right front — cut 1

8. Back neck facing – cut 1
9. Upper sleeve – cut 2
10. Lower sleeve – cut 2
11. Yoke 1 – cut 1
12. Yoke 2 — cut 1
13. Back hem facing — cut 1

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Front lining – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Attention: lining of back and side front are cut using main pattern pieces except for the width of back neckline facing and back hem facing correspondingly.

Fusible interfacing: center front facing, back neck facing, back hem facing, center front, side front, hem of sleeve.

INSTRUCTIONS:

1. Apply fusible interfacing. Apply additional tape of fusible interfacing along front neckline.
2. Sew dart on center front. Press dart towards top. Sew yoke 1 and yoke 2 to right front. Press the seam apart. Sew and press apart princess seam on front.
3. Sew dart on center back. Sew and press apart princess seams on back. Sew and press apart center back seam. Sew and press apart shoulder and side seams of jacket.
4. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing. Sew back hem facing to the central front facings. Press seams apart.
5. Pin the central front facing and the facing onto right side of front, right sides together, pin together and sew center front edge, front neckline, back neckline and hem of jacket. When stitching make sure to place the front piece on top. Topstitch seam allowance of the central front facing onto the central front facing. Place stitch line at 0,2 cm from seam.
6. Sew the elbow seam of the sleeve and press it apart, adjusting ease on upper part of sleeve and matching notches. Press the hem of sleeve. Fold away seam allowance on hem, sew and press apart front sleeve seam.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.

8. Sew seams on lining and sew in sleeves, leaving an opening for turning in left elbow seam. Sew lining to inner edges of the central front facings and to facings.
9. Sew lining to hem of sleeve. Turn jacket right side out. Sew the opening closed.
10. Make buttonhole on right front, on left front sew on a button.
11. Make and baste pleats on decorative collar using slip stitches or hem stitches as desired from the wrong side.

TECHNICAL DRAWING:

