

Tunic With Hood - Sewing Pattern #4742

Recommendations on fabric: natural/mixed knit fabric of small/medium stretchiness.

You will also need: decorative cord, 2 cord end caps.

Seam allowances: all seam allowances – 1.0 cm, seam allowance for hem of garment – 1.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 1 on fold

2. Front – cut 1 on fold
3. Front side – cut 2
4. Pocket bag – cut 2
5. Sleeve – cut 2
6. Front hood – cut 2
7. Back hood – cut 2

INSTRUCTIONS:

1. Pin pocket bag onto front right sides together and sew pocket opening. Fold pocket bag onto wrong side, press.
2. Pin front at front side and sew princess seams and edges of pocket bags with one continuous seam, serge.
3. Sew shoulder seams, press towards the back and serge.
5. Sew sleeves into armholes, serge and press.
6. Sew lower edges of sleeve and side edges with one continuous seam. Press seams towards back and serge.
7. Make buttonholes on front hood (on one of the pieces). Sew upper edge of front hood. Pin front hoods together right sides together and sew along incurved edge. Turn right side out. Sew a decorative stitch at 2 cm from the hood edge, making a casing. Sew the curved edge of back hood. Serge. Sew front hood to back hood. Serge the seam allowances. Sew hood into neckline, serge. Thread the cord into casing, fix the cap end cords.
8. Serge lower edge of garment and lower edge of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

