

Jacket With Zipper - Sewing Pattern #4775

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; shoulder pads; 2 zippers; 1 separating zipper.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Upper side front - cut 2
4. Lower side front - cut 2
5. Center front - cut 2
6. Front placket - cut 4
7. Back neck facing - cut 2

8. Front neck facing - cut 4
9. Sleeve - cut 2

Lining:

1. Center back - cut 2
2. Side back - cut 2
3. Upper side front - cut 2
4. Lower side front - cut 2
5. Center front - cut 2
6. Sleeve - cut 2

Fusible interfacing:

1. Front placket - cut 4
2. Back neck facing - cut 1
3. Front neck facing - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge separately, sew and press apart princess seams on the back (sew side backs to center backs). Sew and press apart center back seam. Sew back neckline facing to back, press the seam allowances towards the facing.
3. Sew zipper to upper and lower side fronts. Sew side fronts to front, press towards center. Sew front neckline facing to facing, press the seam allowances towards the facing. Sew front placket to front.
4. Pin fronts together, right sides together and adjust edges, measuring the lengths of center front edges. Sew zipper to center front edge. Fold center front edges near closure under and press.
5. Sew side and shoulder seams, press the seam apart.
6. Sew the elbow seam of the sleeve and press it apart, adjusting ease on upper part of sleeve and matching notches. Press the hem of sleeve. Fold away seam allowance on hem, sew and press apart front sleeve seam.
7. Sew sleeves into armholes matching notches, adjusting ease along upper side of sleeve cap. Sew shoulder pads.
8. Sew the shoulder edges of inner neckline facings, press the seam apart. Sew seams on lining, sew in sleeves, leaving an opening for turning in left elbow seam. Sew facing into neckline of lining. Sew inner front placket to lining.
9. Place lining onto right side of front, right sides together, pin lining and self together and sew around neckline

and center front edges. When stitching make sure to place the front piece on top.

10. Sew lining to hem of jacket and hem of sleeve. Turn jacket right side out. Sew the opening closed.

TECHNICAL DRAWING:

