

## Neoprene Coat - Sewing Pattern #4793

Recommendations on fabric: double sided stable natural/mixed fabrics suitable for coats, neoprene.

You will also need: 4 buttons.

Seam allowances: all seams 0.5 cm; seam allowance for hem of garment and hem of sleeve - 0 cm; outer seam allowances of collar and center front - 0 cm, seam allowances along pocket bag, welt and underlay piece - 1 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 2
2. Front - cut 2
3. Front sleeve — cut 2
4. Back sleeve - cut 2
5. Collar - cut 1
6. Pocket welt - cut 2

7. Underlay piece - cut 2
8. Small pocket bag - cut 2
9. Large pocket bag - cut 2

## **INSTRUCTIONS:**

1. Mark the position of pocket. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags.
2. Sew darts on back. Press bulk towards center. Pin together backs along center seam, wrong sides together. Sew from the right side so that seam allowances are placed on the right side..
3. Depending on your size, your pattern may or may not feature the front bust darts. Sew these darts now if they are present on your pattern. Press bulk of bust darts towards top.
4. Pin together fronts and backs along side seams and shoulder seams, wrong sides together. Sew from the right side so that seam allowances are placed on the right side..
5. Pin collar onto neckline, wrong sides together. Sew along neckline and lapel line so that seam allowances are places on the right side.
6. Fold sleeve and match together sleeve side edges, wrong sides together. Sew from the right side so that seam allowances are placed on the right side., sew sleeves into armholes.
7. Make buttonholes and sew on buttons.

## **TECHNICAL DRAWING:**

