

Flared Coat - Sewing Pattern #4794

Recommendations on fabric: Coat ткани из натуральных or смесовых волокон.

You will also need: lining; decorative band for sleeve; 7 buttons; shoulder pads; fusible interfacing.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Right center front - cut 1
4. Left center front - cut 1
5. Side front - cut 2
6. Upper sleeve - cut 2

7. Lower sleeve - cut 2
8. Back neck facing - cut 1
9. Center front facing of right front - cut 1
10. Center front facing of left front - cut 1
11. Stand collar -cut 2

Lining:

1. Center back - cut 2
2. Right center front - cut 1
3. Left center front - cut 1
4. Side back - cut 2
5. Side front - cut 2
6. Upper sleeve - cut 2
7. Lower sleeve - cut 2
8. Pocket bag — cut 4

Fusible interfacing:

1. Right center front — cut 1
2. Left center front - cut 1
3. Center front facing of right front — cut 1
4. Center front facing of left front - cut 1
5. Back neck facing — cut 2

Fusible interfacing is also applied to parts of armholes on back, pocket opening and lower edge of garment.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew darts on back, press bulk towards center. Sew side backs to center back, press the seam apart. Sew center back seam. Press apart center seam.
3. Sew darts on front, press bulk towards bottom. Sew pocket bag to center front and to side front. Sew side fronts to center front, sewing the pocket bag edge at the same time. Press the seam apart, clipping into corner on side front. Press pocket towards center.
4. Sew shoulder and side seams, press the seam apart.
5. Sew elbow seam of sleeve and press towards top. Make buttonholes on sleeve. Cut a strap from lining , its width should equal 6 cm, the length should equal the width of sleeve. Fold inside by 1 cm inside and press along longer sides. Pin from the wrong side onto sleeve and topstitch along the marked lines, making a casing. Start and stop stitching exactly at the seam allowance of sleeve. Sew and press front sleeve seam apart, but do not sew and press the lining for casing. Sew a line with short stitches along upper edge of sleeve cap. Собрать

сборку and press gathered ease. Sew sleeves into armholes matching notches and adjusting ease. Sew shoulder pads and sleeve heads to garment.

6. Sew shoulder seams of central front facings and facings, press the seam apart.

7. Stand collars pin together right sides together and sew along the upper edge. Trim seam allowances, clip into curves, turn right side out and press. Sew collar into the coat's neckline.

8. Press seam allowance on lower edge of garment. Place center front facing onto front right sides together. Pin together center front facing and top of garment and sew along the center front edge and along neckline. Sew lower edge of the central front facing to front exactly according to the marked line of hem, stopping before the inner edge of the central front facing at 1.5 cm. Turn center front facings right side out onto right side, straighten seams.

9. Sew seams on lining, leaving an opening in left side seam for turning. Sew рукава. Sew lining to the central front facings and to facing. Sew lining to lower edge of garment. Turn coat right side out through the opening. Sew the opening closed.

10. Make buttonholes on right front, sew on buttons onto left front. Thread decorative band into casing.

TECHNICAL DRAWING:

