

Asymmetrical Jacket - Sewing Pattern #4795

Recommendations on fabric: natural/mixed suiting fabric, companion fabric.

You will also need: fusible interfacing; lining; 8 buttons; shoulder pads, sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance along hem of jacket and hem of sleeve 3 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front - cut 2
5. Stand collar - cut 1
6. Upper sleeve - cut 2

7. Lower sleeve - cut 2
8. Back neck facing - cut 1
9. Center front facing - cut 2

Main fabric 1:

1. Pocket frame - cut 4
2. Inner collar - cut 1

Lining:

1. Center back - cut 2
2. Center front - cut 2
3. Side back - cut 2
4. Side front - cut 2
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2
7. Small pocket bag - cut 2
8. Large pocket bag - cut 2

Fusible interfacing:

1. Center front - cut 2
3. Back neck facing - cut 1
4. Center front facing - cut 2
5. Stand collar - cut 1
6. Inner collar - cut 1
7. Pocket frame - cut 4

Attention: Front and back from lining are cut using the pattern blocks for self fabric, with the exception for the areas of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing. Also apply fusible interfacing to seam allowances along hem of garment and hem of sleeve.
2. Sew darts on back, press bulk towards center. Sew side backs to center back, press towards center. Sew center back seam, press the seam apart.
3. Sew side fronts to front, press towards center.
4. Mark the position of pocket on front. Pin together pocket frames, wrong sides together and press. Mark an additional line of the seam on pocket frame, so that it can be sewn to the front parallel to the fold. Sew bigger pocket bag to upper pocket frame. Sew pocket frames to front. Start stitching exactly at the marked princess seam line on the front. Slash front along the line as marked on the pattern block. Snip diagonally toward end of

stitching at 1-1.5 cm from end of pocket opening. Turn the pocket frames onto the right side through the resulting opening, straighten the edges, adjust the ends of the pocket frames in such a way that the pressed folds meet each other. Fix corners of pockets in place by stitching a double stitch line from the wrong sides at the corners. Sew the smaller pocket bag into the seam of the lower pocket frame. Sew together edges of pocket bags.

5. Sew the shoulder edges and the side edges, press the seam apart of jacket.

6. Sew the stand collar into neckline. Clip into curves, press apart.

7. Sew side seams of back neckline facing and central front facings, press seam apart. Sew inner collar into neckline. Press the seam apart.

8. Pin button stands (center front facings) onto front right sides together and sew center front edge, collars and lower rounded corner, stepping away 1.5 cm from the inner edge of center front facing. Trim away corners, clip into curves. Fold the center front facings onto right side, straighten seams, press. Baste together the seam allowances of stand collar and inner collar along the seam allowance of back neckline.

9. Sew the elbow seam of the sleeve and press it apart. Press the hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap. Sew shoulder pads, sew sleeve heads.

10. Sew seams on lining and sew in sleeves, leaving an opening in left front sleeve seam. Sew lining to inner edges of the center front facings and to the facing. Press lower edge of garment onto wrong side. Sew lining to hem of garment and hem of sleeve. Turn jacket right side out through the opening. Sew the opening closed.

11. Make buttonholes on right front, sew on buttons onto left front.

TECHNICAL DRAWING:

