

## Coat With Hood - Sewing Pattern #4796

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining; shoulder pads; sleeve heads; fusible interfacing; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Center back - cut 1
2. Side back - cut 2
3. Center front - cut 2
4. Side front - cut 2
5. Upper sleeve - cut 2
6. Lower sleeve - cut 2
7. Hood - cut 2

8. Center hood – cut 1
9. Hood facing – cut 1
10. Center front facing – cut 2
11. Back neck facing – cut 1
12. Pocket welt – cut 2
13. Underlay piece – cut 2
14. Belt – cut 1

Lining:

1. Center back – cut 1
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Hood – cut 2
8. Center hood – cut 1
9. Large pocket bag — cut 2
10. Small pocket bag — cut 2

Fusible interfacing:

1. Center front — cut 2
2. Center front facing — cut 2
3. Hood facing – cut 1
4. Back neck facing — cut 1
5. Pocket welt – cut 2

Also apply fusible interfacing to armholes on back and front, pocket entrance, hem of garment and hem of sleeve.

Attention! Lining is cut using pattern blocks for self fabric, except for the width of center front facing and back neckline facing and facings капюшона.

## **INSTRUCTIONS:**

1. Apply fusible interfacing.
2. Sew shoulder darts on center back, press the inner part towards center. Sew side backs to center back, press the seam apart.
3. Sew side fronts to front, press the seam apart.
4. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew

welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew and serge edges of pocket bags.

5. Sew shoulder and side seams, press the seam apart.

6. Sew side hoods to center hood, press the seam apart. Sew hood into neckline, clip seam allowances, press apart.

7. Sew shoulder seams of central front facings and facings, press the seam apart.

8. Sew side hoods cut from lining to center hood, press the seam apart. Sew hood facing to hood lining, press the seam allowances towards the facing. Sew hood into neckline of center front facings and neckline facing, clip into curves, press apart.

9. Serge and press seam allowance along hem onto wrong side. Place center front facing onto front right sides together. Pin together center front facing and self garment and sew along center front and hood. Sew lower edge of the central front facing to front exactly according to the marked line of hem, stopping before the inner edge of the central front facing at 1.5 cm. Turn center front facings right side out onto right side, straighten seams. Baste together the seam allowances along neckline of hood close to the seam.

10. Sew the elbow seam of the sleeve and press it apart. Press seam allowance on lower edge onto wrong side. Sew and press apart front sleeve seam. Sew a line with short stitches along upper edge of sleeve cap. Собрать сборку and press gathered ease. Sew sleeves into armholes matching notches and adjusting ease. Sew shoulder pads and sleeve heads to garment.

11. Sew darts and seams on lining, sew in sleeves. Serge, fold inside and topstitch lower edge of lining. Sew lining to inner edges of the central front facings and to back neckline facing. Sew lining to hem of sleeve.

12. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening for turning. Trim seam allowances in corners, turn belt right side out. Sew the opening closed.

## **TECHNICAL DRAWING:**

