

# **Jacket With Zipper - Sewing Pattern #4799**

Recommendations on fabric: natural/mixed fabrics suitable for outdoor jackets.

You will also need: lining; zipper, polyester padding.

Seam allowances: Все швы 1 cm, seam allowance on lower edge of sleeve – 3 cm.

#### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



## **CUTTING:**

#### Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

## Main fabric:

- 1. Back cut 1 on fold
- 2. Front cut 2
- 3. Sleeve cut 2
- 4. Stand collar cut 2
- 5. Back neck facing cut 1
- 6. Center front facing cut 2



- 7. Pocket welt cut 2
- 8. Lower placket cut 1

## Polyester padding:

- 1. Back cut 1 on fold
- 2. Front cut 2
- 3. Sleeve cut 2
- 4. Stand collar cut 1
- 5. Lower placket cut 1

#### Lining:

- 1. Back cut 1 on fold
- 2. Front cut 2
- 3. Sleeve cut 2
- 4. Large pocket bag cut 2
- 5. Small pocket bag cut 2

#### **INSTRUCTIONS:**

- 1. Pin parts cut from polyester padding onto wrong side of corresponding parts from self fabric and baste around contour. Treat as one piece in the future. Sew decorative stitches each 6-8 cm along front and back, attaching self fabric to polyester padding. Sew decorative stitches along the sleeve.
- 2. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Topstitch underlay piece onto bigger pocket bag, folding long edge under. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew and serge edges of pocket bags.
- 3. Sew shoulder seams on jacket and press apart. Sew рукава.
- 4. Sew side seam and sleeve seam continuously, press apart.
- 5. Sew outer stand collar into neckline. Clip into seam allowances and press apart. Sew outer lower placket to garment. Press towards top.
- 6. Sew shoulder seams of central front facings and facings. Press the seam apart. Sew inner stand collar into neckline. Clip into seam allowances and press apart. Sew inner edge of placket to center front facings. Press towards top.
- 7. Place center front facing onto front right sides together and sew along the center front edge, inserting



zipper, sewing the collar at the same time.

- 8. Sew seams on lining, leaving an opening in left side seam. Sew рукава.
- 9. Baste together seam allowances along the seam of stand collar. Sew lining to the central front facings and to facing. Sew lower edge of lining to upper edge of placket. Sew lining to hem of sleeve. Turn right side out.

## **TECHNICAL DRAWING:**

