

Sheepskin Jacket - Sewing Pattern #4875

Recommendations on fabric: short hair or medium hair sheepskin fabric.

You will also need: 3 push buttons.

Seam allowances: Seam allowance along center front and hem of garment - 4.5 cm. Seam allowance along hem of sleeve, ends of collar and collar fall - 0 cm. Other seams - 1.5 cm

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper front - cut 2
2. Lower front right - cut 1
3. Lower front left - cut 1
4. Back - cut 2
5. Collar - cut 1
6. Upper sleeve - cut 2

7. Lower sleeve - cut 2

INSTRUCTIONS:

1. Sew center back seam, lay out seam allowances flat and topstitch at 0.5 - 0.7 cm from seam.
2. Sew side fronts to front, lay out seam allowances flat and topstitch at 0.5 cm - 0.7 from seam.
3. Sew shoulder and side seams, lay out seam allowances flat and topstitch at 0.5 cm - 0.7 from seam.
4. Fold hem under and topstitch.
5. Pin collar to garment, fur sides together, fold seam allowance of center front onto wrong side and sew the lower corner. Sew upper corner, sewing collar into the neckline at the same time. Fold seam allowance of center front onto right side, topstitch onto front. Topstitch seam allowances of collar onto collar.
6. Sew elbow seam on the sleeve, lay out seam allowances flat and topstitch at 0.5 cm - 0.7 from seam. Sew front sleeve seam. Sew sleeves into armholes matching notches. Fold lower edge of sleeve onto right side, forming a cuff.
7. Sew buttons onto front according to markings.

TECHNICAL DRAWING:

