

Blouse With Flounced Neckline - Sewing Pattern #4876

Recommendations on fabric: thick natural/mixed fabrics suitable for blouses.

Seam allowances: seam allowance for hem of garment and hem of sleeve - 2.0 cm, other seams - 1.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Front - cut 1 on fold
2. Back - cut 1 on fold
3. Collar - cut 1
4. Sleeve - cut 2

INSTRUCTIONS:

1. Sew front darts (if drafted for the size measurements provided). Press bulk towards top.
2. Sew darts on back. Press bulk towards center.
3. Sew shoulder seams, press towards the back and serge.
4. Collar pin together in half lengthwise right side out. Sew a gathering stitch along longer edge and gather fullness. Pin left collar onto right collar and baste together along lower edge. Sew collar into neckline, slashing corners, press the seam allowances towards the main piece and serge. Topstitch seam allowances onto Shell at 0.5 cm.
5. Sew sleeves into armholes, matching notches, serge and press. Sew sleeve seams and continue sewing side seams, serge and press.
6. Serge the lower edge of garment and the lower edge of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

