

Dress With Fly Pieces From Chiffon - Sewing Pattern #4922

Recommendations on fabric: guipure, chiffon and natural/mixed fabric suitable for dresses in matching colours.

You will also need: dress zipper.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment - 2 cm. Seam allowances along lower edges of fly back piece and fly front piece - 1 cm. Seam allowance along center edge of fly front piece - 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric(guiPURE):

1. Back - cut 2
2. Front - cut 1 on fold
3. Sleeve - cut 2
4. Front yoke - cut 1
5. Back yoke - cut 1

Main fabric 1 :

1. Lower back - cut 1
2. Lower front - cut 1 on fold
3. Front lining - cut 1 on fold
4. Back lining - cut 2

Lining for front and back is cut using the pattern blocks for main fabric. (guipure)

Chiffon:

1. Back fly piece - cut 1 on fold
2. Front decorative piece - cut 2

INSTRUCTIONS:

1. Sew darts on fronts and on backs. Press bulk of waist darts towards center, press bulk of bust darts towards top.
2. Sew darts on front lining and back lining. Press bulk of waist darts towards center, press bulk of bust darts towards top. Pin Shell onto Lining, baste together along side edges, upper edges and armhole edges. Treat as one piece in the future.
3. Sew right side edge. Serge seams and press towards back. Serge left side edges separately. Sew side seam from armhole to marking, and from marking up to hem. Press the seam apart, sew in zipper.
4. Sew side seams on lower parts. Sew lower part to dress, serge and press towards top.
5. Sew shoulder seams on yokes. Serge seams and press towards back. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of neckline + 3 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew. Turn bias tape onto wrong side and topstitch onto main piece along the seam. Press seam.
6. Sew side seams of fly pieces. Serge seams and press towards back. Serge center and lower edges of fly pieces, press inside and topstitch. Or sew a thin rolled hem, in this case please cut away seam allowances.
7. Pin fly part onto dress, right side up, and baste together along upper edges and armhole edges. Sew yokes to front and to back. Serge seams and press towards top.
8. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes, serge and press.
9. Serge hem of dress, turn inside and topstitch.

TECHNICAL DRAWING:

