

## Boho Dress - Sewing Pattern #4937

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; bias tape - 6 cm; decorative band; lining.

Seam allowances: Seam allowance for hem of garment - 2 cm; hem of sleeve - 2 cm; side seam allowances of collar 2 cm; other seams - 1 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Pocket welt - cut 2
4. Back sleeve - cut 2
5. Front sleeve - cut 2
6. Collar - cut 1

7. Underlay piece - cut 2

Lining:

1. Large pocket bag - cut 2
2. Small pocket bag - cut 2

Fusible interfacing:

1. Pocket welt - cut 2

## **INSTRUCTIONS:**

1. Apply fusible interfacing to off-set welts.
2. Sew darts on front. Press bulk towards top.
3. Mark the position of pocket. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags. Serge seam allowances.
4. Sew sleeves to front. Serge the seam allowances and press onto sleeve.
5. Sew sleeves to back. Serge the seam allowances and press onto sleeve.
6. Sew upper edge of sleeve. Serge and press towards back part of sleeve.
7. Sew side seams. Serge seams and press towards back.
8. Finish the area of neckline that is marked by notches, and is 3 cm long, with bias tape. Turn under side seam allowances of collar at 1 cm, then again at 1 cm and topstitch. Sew the outer collar into neckline, seam allowance fold at collar. Fold under the seam allowance of the inner side inside and stitch-in-the-ditch along seam of outer side.
9. Serge hem of garment and hem of sleeve, turn inside and topstitch.
10. Thread decorative band into the collar.

**TECHNICAL DRAWING:**

