

Jacket With Slanted Closure - Sewing Pattern #4960

Recommendations on fabric: natural/mixed suiting fabrics in similar or contrasting colours.

You will also need: lining; fusible interfacing; 2 of the zipper; 1 separating zipper.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

- 1. Center back cut 2
- 2. Center front cut 2
- 3. Upper sleeve cut 2
- 4. Lower sleeve cut 2

Main fabric 1:



- 1. Side back cut 2
- 2. Side front cut 2
- 3. Front yoke cut 2
- 4. Stand collar cut 2
- 5. Center front facing cut 2
- 6. Back neck facing cut 1

Fusible interfacing:

- 1. Center front cut 2
- 2. Stand collar cut 1
- 3. Center front facing cut 2
- 4. Back neck facing cut 1

Lining:

- 1. Center back cut 2
- 2. Side back cut 2
- 3. Front lining cut 2
- 4. Upper sleeve cut 2
- 5. Lower sleeve cut 2

Attention: Back lining is cut using the pattern blocks for self fabric, except for the width of back neckline facing.

INSTRUCTIONS:

- 1. Apply fusible interfacing.
- 2. Sew shoulder darts, press the inner part towards center. Sew side backs to center back, press towards center. Sew center back seam, press the seam apart.
- 3. Sew yoke to front, press seam allowances towards yoke. Sew side fronts to front, press towards center.
- 4. Mark the position of pockets with parallel lines. Cut the slit for pocket opening. Slash diagonally at 1-1.5 cm from the end of the marked slit. Turn the seam allowances onto the wrong side through the resulting opening, straighten edges. Pin zipper under the opening so that you can see the teeth and sew.
- 5. Sew side and shoulder seams, press the seam apart.
- 6. Pin together parts of stand collar, right sides together and sew ends and outer edge. Clip into curves, trim away corners. Turn stand collar right side out, straighten, press. Sew the stand collar into neckline.
- 7. Sew side seams of center front facings and back neckline facings, press the seam apart. Pin left part of zipper onto left front according to markings and topstitch.



- 8. Sew right side of zipper to the edge of right front, teeth are directed away from the edge. Pin center front facings onto garment, right sides together, and sew center front edge, neckline (stand collar is placed between facing and shell) and lower corner of center front. Clip into curves, trim away corners, turn pieces right side out. Sew a decorative stitch along lapel and center front at 0.5 0.7 cm.
- 9. Sew elbow seam on sleeve, press the seam apart. Press the hem of sleeve. Sew front seam on sleeve, press the seam apart. Sew sleeves into armholes matching notches.
- 10. Sew seams on lining and sew in sleeves, leaving a technical opening in the right front sleeve seam. Press seam allowances of lining.
- 11. Sew lining to the central front facings and to facing, press seam. Turn garment right side out, straighten seams.
- 12. Mark and press lower edge of garment. Sew lining to hem of sleeve and hem of garment. Turn the jacket right side out through the technical opening in the sleeve. Sew the opening in the sleeve closed.

TECHNICAL DRAWING:



