

Jacket From Two-Side Fabric - Sewing Pattern #4963

Recommendations on fabric: thick natural/mixed two-side fabrics with short hair.

You will also need: 1 separating zipper; bias tape; lining.

Seam allowances: all seams 1 cm. Seam allowances along hem of garment, hem of sleeve, collar fall - 2 cm, outer center front edge - 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Side front - cut 2
3. Center front - cut 2
4. Back yoke - cut 1
5. Front yoke - cut 2
6. Lower placket - cut 1

7. Collar - cut 1
8. Sleeve - cut 2
9. Pocket frame - cut 4

Lining:

1. Large pocket bag - cut 2
2. Small pocket bag - cut 2

INSTRUCTIONS:

1. Sew center back edges, serge and press apart. Sew back yoke to garment. Serge and press onto yoke. Sew a decorative stitch from the right side at 0.5 cm from seam.
2. Sew yoke to side front, press seam allowances towards yoke, serge. Sew a decorative stitch from the right side at 0.5 cm from seam.
3. Mark the position of pockets with parallel lines. Pin together pocket frames, wrong sides together and press. Mark an additional line of the seam on pocket frame, so that it can be sewn to the front parallel to the fold. Sew bigger pocket bag to upper pocket frame. Sew pocket frames to front. Slash front along the line as marked on the pattern block. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn the pocket frames onto the right side through the resulting opening, straighten the edges, adjust the ends of the pocket frames in such a way that the pressed folds meet each other. Fix corners of pockets in place by stitching a double stitch line from the wrong sides at the corners. Sew the smaller pocket bag into the seam of the lower pocket frame. Sew and serge edges of pocket bags. Baste lower and center seam allowances to shell, treat as one piece in the future.
4. Sew side seams, press the seam apart, serge. Sew lower placket to jacket. Serge and press towards top. Sew a decorative stitch from the right side at 0.5 cm from seam.
5. Sew the right princess seam on front, serge and press towards side. Serge separately the edges of the left princess seams, insert the left part of zipper from hem up to the big marking and sew. Press towards side seam, sew a decorative stitch at 0.5 cm from seam.
6. Sew side seams, press the seam apart, serge.
7. Serge the left center front edge. Sew right side of zipper to the edge of right front, teeth are directed away from the edge. Press onto wrong side and sew a decorative stitch along center front edge at 0.5 cm. Trim away seam allowance of left front edge to 1 cm, serge. Fold away seam allowance onto wrong side and topstitch at 1.5 cm from the edge.
8. Fold seam allowance along collar fall onto the wrong side and fix it with a thin zigzag stitch. Pin collar to jacket wrong sides together and sew collar into neckline. Straighten collar. Fold seam allowance towards bottom. Pin a bias tape onto the seam, covering it, and topstitch.

9. Sew sleeve seam, serge and press apart. Press the hem of sleeve onto right side. Fix the seam allowance along hem on the right side with a thin zigzag stitch. Sew sleeves into armholes matching notches.

10. Serge and press towards top lower edge of garment. Topstitch at 1.5 cm from the edge.

TECHNICAL DRAWING:

