

Coat With Sleeves From Main Fabric Or Knit - Sewing Pattern #4984

Recommendations on fabric: stable natural/mixed fabrics suitable for coats, neoprene, felt.

You will also need: knit fabric for sleeves; 3 push buttons.

Seam allowances: all seams 1 cm; seam allowance for hem of coat and hem of sleeve from woven fabric – 0 cm; seam allowance for hem of sleeve from knit fabric – 3 cm; outer seam allowances of neckline and center front – 0 cm; lower seam allowance of flap – 0 cm.

Note on seam allowances:

If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use

(usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.





Main fabric:

Upper back - cut 2
 Upper front - cut 2
 Lower back - cut 2
 Lower front - cut 2
 Front sleeve - cut 2
 Back sleeve - cut 2
 Flap - cut 2

If you choose to sew this garment with sleeves from knit fabric:

Knit fabric: 1. Sleeve – cut 2.

INSTRUCTIONS:

1. Serge center edges of upper backs. Pin left back onto right back, matching the marked stitch lines, and topstitch from the right side. Sew lower back in the same way.

2. Sew side and shoulder seams of upper parts. Serge the seam allowances and press apart.

3. Serge front edges of sleeves. Pin upper sleeve onto lower sleeve, matching the marked stitch lines, and topstitch from the right side. Sew elbow seam on sleeve. Serge the seam allowances and press apart. Sew sleeves into armholes. Serge and press.

4. Serge lower and side edges of flaps. Pin flaps onto lower front and baste together along upper edge.

5. Serge side edges of lower parts. Pin lower back onto lower front, matching the marked stitch lines, and topstitch from the right side.

6. Serge lower edge of upper parts. Serge upper seam allowance of lower parts of coat. Pin upper part onto lower part part, matching the marked stitch lines, and topstitch from the right side. Attention! Side seam allowance of lower part is shifted towards front.

7. Serge center front edge, neckline and hem of coat continuously. Serge hem of sleeve.

8. Sew push buttons.

With sleeve from KNIT fabric:

1. Serge center edges of upper backs. Pin left back onto right back, matching the marked stitch lines, and topstitch from the right side. Sew lower back in the same way.



2. Sew side and shoulder seams of upper parts. Serge the seam allowances and press apart.

3. Sew sleeve seam. Serge the seam allowances and press apart. Sew sleeves into armholes, serge and press.

4. Serge lower and side edges of flaps. Pin flaps onto lower front and baste together along upper edge.

5. Serge side edges of lower parts. Pin lower back onto lower front, matching the marked stitch lines, and topstitch from the right side.

6. Serge lower edge of upper parts. Serge upper seam allowance of lower parts of coat. Pin upper part onto lower part, matching the marked stitch lines, and topstitch from the right side. Attention! Side seam allowance of lower part is shifted towards front.

7. Serge center front edge, neckline and hem of coat continuously.

8. Serge hem of sleeve. Fold inside the seam allowance and topstitch with special elastic or narrow zig-zag stitch.

9. Sew push buttons.

TECHNICAL DRAWING:



