

Sewing Pattern — Dress 7177

Recommendations on fabric: silk fabric suitable for dresses.

You will also need: elastic yarn, tape of 5 - 8 cm width (length is shown on dress pattern)

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: on hem and sleeve edge - 2 cm, on neckline edge - 2 cm, all other edges - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Dress – 2 details
2. Sleeve – 2 details
3. Lining – 2 details

ATTENTION: LINING DETAILS ARE CUT FROM MAIN FABRIC

INSTRUCTIONS:

1. Sew shoulder seams. Serge seams and press towards back part. Serge upper edge of the dress. Turn seam allowance inside and topstitch.
2. Put stitches with elastic yarn on marked lines on the dress (except the lowest) and sleeve.
3. Sew side seams. Serge seams and press towards back part.
4. Sew edge of sleeve. Serge and press on back part. Sew sleeve into armhole. Serge and press to sleeve. Serge lower edge of sleeve, turn inside and topstitch.
5. Sew side seams of lining. Serge seams and press towards back part. Serge upper edge of lining. Insert lining into dress and fix on lower marker. Stitch with elastic yarn, sewing lining.
6. Serge lower edge of lining. Turn seam allowances onto wrong side, press and topstitch. Sew tape into ring. Topstitch tape on lining.
7. Serge lower edge of the dress. Turn seam allowances onto wrong side, press and topstitch.

TECHNICAL DRAWING:

