

## Sewing Pattern — Jacket 4309

Recommendations on fabric: woolen costume fabric

You will also need: interfacing; 1 button; lining; small shoulder raglan pads.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

SEAM ALLOWANCE: all seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

### **CUTTING:**

#### Fabric:

1. Stand collar - 2 details
2. Side back – 2 details
3. Center back – 2 details
4. Center front – 2 details
5. Upper side front – 2 details
6. Lower side front – 2 details
7. Button stand – 2 details
8. Back neckline facing – 1 detail
9. Lower facing of back— 1 detail
10. Back part of sleeve – 2 details
11. Front part of sleeve – 2 details
12. Flap – 2 details
13. Pocket frame— 4 details

#### Lining:

1. Center front– 2 details
2. Side front – 2 details
3. Side back - 2 details
4. Center back– 2 details
5. Back part of sleeve – 2 details
6. Front part of sleeve – 2 details
7. Big pocket bag - 2 details
8. Small pocket bag – 2 details



Fusing:

1. Front– 2 details
2. Button stand – 2 details
3. Back neckline facing – 1 detail
4. Upper collar – 1 detail

ATTENTION: front, back and sleeve details from lining are cut except for the width of button stands and back neckline facing respectively

**INSTRUCTIONS:**

1. Apply interfacing to details. Apply bias tape that is from interfacing to lower edge of upper front and top edge of lower front. Apply bias tape from interfacing to pocket location on side back. The width of bias tape is 2 cm.
2. Sew and press apart princess seams on back part. Stitch back parts of sleeves to back.
3. Stitch upper side front to center part from top edge up to lower notch. Press seams towards front's center. Stitch front parts of sleeves to fronts. Press seams apart.
4. Sew lower edges of sleeves and side edges with one seam. End the stitch near lower edge of upper side front. Press seams apart. Stitch lower side front to side back, leveling details from lower edge. Press seams apart.
5. Fold flap details right sides together and overstitch. Trim seam allowances on rounded parts, turn details right side out and press.
6. Mark connection line of flap and frame on side back (leveling to flap width). Fold frames of pocket in half wrong sides together and press. Mark additional line on frame of pocket to stitch it parallel to the fold. Mark additional line on flap to stitch it parallel to top edge of flap. Stitch top pocket bag to flap. Stitch frames to front. Start the stitch exactly near marked line of princess seam of front. Cut side back along line that is marked on pattern. Make cross slashes at 1-1.5 cm off the end of pocket. Turn frames wrong side out through the given slit, straighten edges, straighten ends of frames so that pressed folds of frames go edge-to-edge. Fasten corners of pocket from wrong side with double back stitch on corners basing. Set flap into pocket and stitch to top frame of pocket. Stitch lower pocket bag into connecting seam of lower frame. Sew edges of pocket bags.
7. Tack together frames of pocket. Sew lower section of princess seam of front, turning pocket bags back. Press seam towards center of front.
8. Sew center edge of back. Press seam apart. Sew upper collar into the neckline. Press seam apart.
9. Sew shoulder and top edges of sleeves. Trim seams on rounded parts and press them apart. Sew in shoulder pads.
10. Sew lower collar into the facing neckline. Press seam apart. Sew shoulder edges of back neckline facing and button stands. Trim seams on rounded parts and press them apart. Stitch hem facing of back to button stand. Press seams apart.
11. Sew seams and sew in sleeves on details from lining, leaving a slit in top part of left side seam. Stitch lining to inner button stand edges and to facings.
12. Put button stand with facing onto right side of front, right side downwards, pin together and overstitch button stand, upper edge of collar and hem of jacket. Overstitch from front side. Topstitch allowance of button stand seam onto button stand. Stitch at 0.2 cm off the seam.
13. Overstitch hem of sleeve in two steps. Turn sleeves out and press.
14. Turn jacket right side out. Sew the slit. Remove tacks of pocket.
15. Make buttonhole and sew a button on fronts.

**TECHNICAL DRAWING:**

