

Sewing Pattern — Sweatshirt Jacket 4336

Recommended fabric: knit fabric of medium stretchiness

You will also need: fusible interfacing, a long separating zipper and two sleeve zippers (length is shown on corresponding pattern pieces).

Seam allowances are provided if the pattern has double contour.

Seam allowances are NOT included if the pattern has single contour and need to be added when laying out and cutting pieces.



Seam allowance: on hem of the garment and hem of sleeve — 1.5 cm, all other seams – 0.8 cm .

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

(On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.)

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Main fabric:

1. Back - cut 2
2. Left front - cut 1
3. Right front – cut 1
4. Sleeve – cut 2
5. Collar – cut 2
6. Button stand of left front –cut 1
7. Button stand of right front – cut 1

Interfacing:

1. Collar – cut 1
2. Button stand of left front – cut 1
3. Button stand of right front – cut 1

Advice:

Knit fabric details are sewn together with special elastic, narrow zig-zag stitch, or can be serged using an overlock machine. Seam allowance on hem is stitched with double needle to save stretchiness.

INSTRUCTIONS:

1. Apply fusible interfacing to collar and button stand.
2. Sew center edge of back. Serge seam allowance.
3. Sew darts on fronts. Press toward hem.
4. Sew shoulder seams. Serge seams and press towards back.
5. Sew lower collar into the neckline. Press seam allowance onto collar. Serge top and outer edges of button stands. Stitch button stands to top collar. Press seam open. Place button stands/top collar onto fronts, right sides together, matching marks and seams. Sew seam. Turn button stand and collar to wrong side and press. Turn lower edge top of collar inside and topstitch into lower collar connecting seam. Place separating zipper on right button stand, and stitch so that zipper blade extends edge of button stand at 0.5 cm. Topstitch on right front.
6. For left part of zipper, place along diagonal mark for zipper on left front. Topstitch.
7. Serge hem of sleeve. Turn seam allowance inside and topstitch. Topstitch short zipper on sleeve according to marks. Sew sleeve into open armhole matching marks. Serge seam allowance. Sew side edge and edge of sleeve in one step. Serge seam allowance.
8. Serge hem of the garment. Press onto wrong side, rounding button stand, and topstitch.

TECHNICAL DRAWING:

