

Sewing Pattern — Dress 4367

Recommendations on fabric: lightweight denim

You will also need: zipper, fusible interfacing, 7 buttons

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam Allowance: all seams - 1 cm; on hem of the dress – 1.5 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Upper back - cut 2
2. Center lower back - cut 2
3. Side lower back - cut 2
4. Upper left front - cut 1
5. Upper right front - cut 1
6. Side front – cut 2
7. Lower front - cut 2
8. Back inset -cut 2
9. Lower back trim - cut 1
10. Front inset - cut 1
11. Lower front trim - cut 1
12. Back yoke/facing– cut 4
13. Left front yoke/facing – cut 2
14. Right front yoke/facing – cut 2
15. Flap – cut 2

Interfacing:

1. Back facing – cut 2
2. Left front facing – cut 1
3. Right front facing – cut 1

INSTRUCTIONS:

1. Apply interfacing to facings.
2. Sew darts on upper backs, press darts toward center. Stitch back yoke to upper back. Trim corner corners and clip into curve. Press seam allowance toward yoke. Stitch back inset to upper back, serge and press seam toward inset.
3. Sew lower center and side backs, serge and press seam allowances toward center. Stitch lower back to back inset, serge and press seam toward inset.
4. Serge separately center edges of back. Sew center back seam from zipper mark to hem, press seam allowances apart, including opening for zipper. Sew in zipper. Sew lower back trim to back, serge and press seam toward trim.
5. Sew darts on upper fronts, press darts toward hem. Sew upper center and side fronts, serge and press seam allowances toward center.
6. Stitch front yokes to upper parts, trimming corners and clipping into curves. Press seam allowances toward yokes. Serge center edge of upper left front.
7. Sew shoulder seams, press seam allowances open. Sew shoulder seams of yoke facings, press seam allowances open. Pin facing right sides together on dress and stitch on right front edge and back / front neckline edges. Trim corners and clip into curves. Understitch where possible. Turn facing onto wrong side, straighten, press. Topstitch facing into connecting seam.
8. Pin right front on left front, matching notches, and fasten with buttons, sewing them through both fronts.
9. Sew front inset to upper front, serge and press seam onto inset. Sew lower front trim to lower front, serge and press seam toward trim. Make and fasten pleats according to marks. Sew lower front to upper front, serge and press seam allowances upwards toward bodice.
10. Fold flap in half lengthwise, right sides together, and sew outer edges. Trim seam allowances in corners, turn right side out, press.
11. Sew side seams, inserting flaps, serge and press seam toward back.
12. Sew side seams of the facings, press seam allowances apart. Sew armhole in two steps: first back edge of sleeve, then front front edge of sleeve. Clip into curves, turn facings onto wrong side, press. Topstitch facing on garment into connecting seam. Tack facing to zipper tape.
13. Serge lower edge of dress, press onto wrong side, and topstitch.
14. Sew buttons on flap.

TECHNICAL DRAWING:

