

## Sewing Pattern — Dress 5884

Recommendations on fabric: thin costume fabric.

You will also need: blind zipper; lining.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance: on hem – 2 cm, all other seams - 1 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Main fabric:

1. Upper front – 1 detail
2. Front yoke – 1 detail
3. Lower center front – 1 detail
4. Lower side front – 2 detail
5. Upper back – 2 details
6. Back yoke – 2 details
7. Lower center back – 2 details
8. Lower side back – 2 details

Use main fabric pattern pieces to cut out lining. Lining is 5 cm shorter.

### **INSTRUCTIONS:**

1. Mark and sew darts on upper back. Press darts towards center of back. Stitch yoke to back. Serge seam and press in onto yoke.
2. Sew lower center and side back parts. Press seam towards center of back and serge. Stitch lower back to back yoke. Serge seam and press it onto yoke. Serge center edges of back. Sew center seam from zipper mark up to slit. Press seam apart, pressing slit for zipper. Sew in zipper.
3. Stitch loosely on lower edge of upper front and gather ruffles between notches. Stitch yoke to front. Serge seam and press it onto yoke. Sew together lower front parts. Press seam towards center of front and serge. Stitch lower front to yoke. Press seam onto yoke and serge.
4. Sew side seams. Serge seams and press them towards back.

5. Sew details of lining the same way as main fabric details. Put together main fabric details and lining details with their right sides touching, leveling back neckline edges. Leaving 5 mm to zipper edges, turn lining back and pin to top edge of the dress. Turn seam allowances along zipper onto right side of the dress and pin to neckline edge on top of lining. Overstitch neckline edge. Slash seam on rounded parts, turn details out and press. Turn seam allowances along zipper onto wrong side. Tack lining of back to zipper tape. Press details.
6. Overstitch edge of the armhole with lining. Slash seam allowances, turn right side out and press. Set in straps of back between main fabric and front's lining. Overstitch neckline of front, stitching straps in at the same time. Turn details out and press
7. Serge hem seam allowance, press onto wrong side and undersew with invisible stitches.
8. Press hem seam allowance from lining to wrong side twice at 1 cm and topstitch.

**TECHNICAL DRAWING:**

