

Sewing Pattern — Dress 5820

Recommendations on fabric: natural or mixed fabric suitable for dresses.

You will also need: fabric for decoration, invisible zipper, fusible interfacing.

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: all seams – 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches, they must match up with corresponding pieces.



CUTTING:

Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Side front - cut 2
4. Center front – cut 1
5. Back border - cut 1
6. Front border- cut 1
7. Yoke facing - cut 1

Decoration fabric:

1. Yoke - cut 1
- (style option: use decorative fabric for front and back border)

Interfacing:

1. Yoke facing – cut 1

INSTRUCTIONS:

1. Apply interfacing to main fabric yoke facing.
2. Sew side fronts to front, and side backs to back. Serge and press seam allowances towards center. Topstitch at 0.5 cm from the seam.

3. Serge back and front armholes edges, press onto wrong side and topstitch at 0.5 cm.
4. Sew the yoke from decoration fabric to top edge of back, clip into curves and press seam toward yoke.
5. Serge center edge of backs separately. Sew back center seam from zipper notch down to hem. Press seam apart, including opening for zipper. Sew in zipper from top edge of yoke, down to notch.
6. Sew the yoke from decoration fabric to top edge of front, clip into curves and press toward yoke. Press unsewn lower edge of yoke to wrong side.
7. Place yoke facing and yoke, right sides together, and sew to neckline edge. Press seam allowances, and clip into curves. Turn facing onto wrong side, serge lower edge. Press seam allowance of lower edge of facing onto wrong side and topstitch into facing connecting seam, sewing facing to yoke along top armhole edge at the same time. Turn back edges inside, and slipstitch to zipper tape.
8. Press back and front borders in half lengthwise, wrong sides together. Sew back border to back, serge seam and press seam toward border. Topstitch at 0.5 cm from the seam. Sew front border to front, serge seam and press toward border. Topstitch at 0.5 cm from the seam.
9. Sew side seams, serge and press toward back. If desired, topstitch at 0.5 cm from the seam.

TECHNICAL DRAWING:

