

Sewing Pattern — Dress with Decorative Insert 5517

Recommendations on fabric: natural/mixed fabric.

You will also need: zipper of 25 cm length.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 2 cm for garment hem.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part – 2 pieces
2. Upper front part – 1 piece
3. Lower front part – 1 piece
4. Decorative insert – 1 piece

INSTRUCTIONS:

1. Stitch the insert to upper front part. Neaten joining seam and press it upwards. Stitch lower front part to insert. Neaten joining seam and press it downwards.
2. Stitch back/front darts. Press back darts towards back center, press front darts towards front center. Stitch bust darts, press downwards.
3. Stitch dress side seams and neaten them. Press side seams backwards.
4. Neaten dress middle seam. Stitch middle seam up to closure notch, press the seam apart. Stitch the zipper in.
5. Neaten back décolleté edge, front/back armhole edges, front neckline edge. Press neaten edges into wrong side and topstitch them.
6. Cut shoulder straps. Fold straps along the center wrong side out and make a stitch at 0.5 cm from bending. Turn straps right side out and press them. Stitch straps to front neckline.
7. Try the dress, adjust straps' length and sew back ends on back part.

8. Neaten dress hem, fold it under and topstitch at 1.5 cm from lower edge.

TECHNICAL DRAWING:

