

## Sewing Pattern — Lingerie 5785

Recommendations on fabric: fabric of natural or mixed fiber, silk, chiffon

You will also need: bias tape (the approximate length is mentioned on the front piece pattern)

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance on the top edge of the front and back piece and armhole - 0 cm. Stay stitch 1 cm on all edges

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Back - cut 1
2. Side front - cut 2
3. Center front - cut 1
4. Side trim - cut 1



### **INSTRUCTIONS:**

1. Mark and sew waistline darts on back, and press toward center.
2. Sew side fronts to center front. Serge edges and press toward center.
3. Fold the bias tape in half lengthwise, wrong sides together, press. Finish the front and back neck edges with the bias tape. Finish the armholes of the back and front, at the same time making the shoulder straps (measure and mark the length of shoulder strap section on the bias tape before you sew it to armholes).
4. Serge the side edges of the front and back. Press the seam allowances of the sides onto the wrong side, and topstitch.
5. Serge the lower edge of garment, turn onto wrong side, and topstitch.
6. Serge long edges of side trim. Press seam under, and topstitch.
7. Cut side trim into 8 parts, serge the short edges, make a bow out of each part following the drawing, and fasten together in the middle with a couple of stitches.
8. Pin the bows under the side edges of the front and back, matching the marks, and sew them to the side seams.

### **TECHNICAL DRAWING:**

