


Pattern S6001



PATTERN OVERVIEW

Made-to-measure pattern:

The pattern is drafted by our proprietary software specifically for your measurements that you supply when making an online order. We strongly recommend that you request a free preview to check the style lines and the amount of fabric needed before ordering the paid version.



Pattern features:

Semi-fitted sport-style t-shirt with V-neck and short sleeves.

Recommendations on fabric: knit fabric.

Seam allowances:

If the pattern has double contour the seam allowances are included and are as follows: ½ inch on all seams. <u>Attention!</u> Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Fabric requirements:

To estimate fabric requirements, get a free preview for the pattern in your size at www.Lekala.net and use Online Fabric Estimator. Alternatively you may print all the paper patterns and lay them out at the width of fabric you plan to use (usually 44 inches to 60 inches) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must match up.



Pattern S6001



CUTTING:


Lay pattern pieces out using the straight of grain line. Some pieces may be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Main fabric:

- 1. Sleeve cut 2 (A)
- 2. Back cut 1 (B)
- 3. Front cut 1 (C)

Trimming:

Neck Binding ('Collar' on pattern piece)
cut 1 (D)



^{*} The capital letters in brackets correspond to pattern blocks as seen in Online Fabric Estimator and in <u>sample</u> layouts on the right.

Advice: Knit fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hem is stitched with twin needles to save stretchiness. Pieces can also be sewn together with 3 or 4 - thread serger. When serging, cut seam allowances to 0.6 - 0.8 cm.

sewist

Pattern S6001



INSTRUCTIONS:

- 1. Sew shoulder seams. Serge and press them to back.
- 2. Sew sleeves into open armhole, serge seams. Topstitch along connecting seam.
- 3. Sew the garment/sleeve side seams together with one continuous stitch. Serge and press them toward back.
- 4. Sew ends of neck binding, fold in half lengthwise, wrong sides together, and press. Pin binding to neckline from right side slightly stretching it. Baste in place. Serge seam allowances, turn inwards, and press. Topstitch along binding with a stretch-stitch.
- 5. Serge sleeve edge and hem edge. Turn under, press, and topstitch with a stretch-stitch.

If you have any further questions regarding the pattern,

please don't hesitate to contact us at infoasewist.com.

We are always happy to help!