

Sewing Pattern — Top 5670

Recommendations on fabric: middle/high stretchable jersey (natural or mixed)

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 0.5 cm for the hem, 1 cm for other seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

- 1. Back part 1 piece
- 2. Front part 2 pieces
- 3. Front yoke 2 pieces
- 4. Sleeve 2 pieces
- 5. Collar 1 piece

NB! Please make doubt that person's head passes through the ring-stitched before you begin sewing.

Our advice: stitch jersey details with special elastic/zig-zag stitches. If you use an overlock, cut seam allowances till 0.6-0.8 cm width. Topstitch hem allowances with double needle to save elasticity.

INSTRUCTIONS:

- 1. Slash front part's allowance at relieve edge mark. Neaten the edge between the neckline and the mark, press it into wrong side, and then topstitch.
- 2. Neaten front lower edge/wrap edge, press them into wrong side, then topstitch.
- 3. Make front pleats. Fix pleat ends with stitches.
- 4. Stitch front yoke to front part. Neaten seams and press them.



- 5. Lay one front part on another to make a wrap, then fix them together. Coincide front edges and back edges. Side front edge is 1.5 cm shorter than lower back edge. Stitch side edges together. Neaten seams and press them.
- 6. Stitch shoulder front/shoulder back edges. Neaten seams and press them backwards.
- 7. Stitch sleeve seams. Neaten seams and press them.
- 8. Stitch sleeves into armholes coinciding notches. Neaten seams and press them.
- 9. Neaten lower back edge/sleeve lower edges. Press them into wrong side, then topstitch.
- 10. Stitch the collar as a ring. Press the collar along the center wrong side out. Stitch outer collar to back neckline/yoke coinciding edges. Collar seam is at shoulder left seam. Fold collar allowances under and stitch them together.

TECHNICAL DRAWING:

