

Sweat-Shirt - Sewing Pattern #2035

Recommendations on fabric: fleece, footer or natural/mixed thick knit fabric of small stretchiness.

Seam allowances: all seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Front – cut 1 on fold
2. Back – cut 1 on fold
4. Sleeve – cut 2
5. Front facing – cut 1
6. Back facing – cut 2

INSTRUCTIONS:

1. Serge outer edge of front facing. Pin front facing onto front, right sides together and sew lower edge. Fold facing onto wrong side and topstitch along the marked line.
2. Sew shoulder seams. Serge seams and press towards back.
3. Sew sleeves into armholes. Serge the seam allowances and press onto sleeve.
4. Sew center seam of back facing. Press the seam apart. Serge outer edge of back facing. Match side edges of front and back, inserting front between back and back facing. Sew sleeve seams, side seam and hem with one continuous stitch. Trim seam allowances on curves, fold back facing onto wrong side and topstitch along the marked lines.
5. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of neckline + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the seam. Press seam.
6. Fold one-piece cuff onto wrong side. Seam allowance for hem of sleeve fold inside and topstitch. Fold one-piece cuff onto right side.

TECHNICAL DRAWING:

