

Top With Fly Piece - Sewing Pattern #2102

Recommendations on fabric: natural/mixed knit fabric of medium stretchiness.

Seam allowances: all seam allowances – 1 cm. Seam allowance for hem of garment, seam allowance along center edge of front fly piece – 1.2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:

Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold



3. Front decorative piece - cut 1

INSTRUCTIONS:

1. Sew bust darts on front and on front fly piece, press bulk towards top.
2. Sew center and lower edges of the front fly piece, press onto wrong side and topstitch. Pin front fly piece, wrong side down, onto the right side of front and baste together along the right shoulder edge, side edge and armhole edge.
3. Sew right shoulder seam, press towards the back and serge.
4. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of neckline + 5 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the seam. Press seam.
5. Make and baste pleats on the left shoulder edge of front fly piece. The bulk should be on the right side, and directed toward neckline. Baste together the left shoulder edges of front and front fly piece.
6. Sew left shoulder seam, press towards the back and serge.
7. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side and sew, fold bias tape onto wrong side and topstitch onto main piece along the seam.
8. Sew side seams, press towards the back and serge.
9. Serge the lower edge of garment, press onto wrong side and topstitch.

TECHNICAL DRAWING:

